

To Turn it on, set the pin as output and send logic 1 (High) (5 Volts) to the corresponding pin that is connected to Piezo

Here is a code example

```
void main() {  
  TRISB=0B00000000;  
  PORTB=0B00000001;  
}
```

Pizeo on and off with 200 millisecond delay

```
void main() {  
  TRISB=0B00000000;  
  PORTB=0B00000001;  
  delay_ms(200);  
  TRISB=0B00000000;  
  PORTB=0B00000000;  
  delay_ms(200);  
}
```