
## Four Types of Faults!



- Open Disconnected Wire or Component or a Physical Break in the Wire or Component
- <u>High Resistance</u> Poor Connection or Corrosion on a wire, switch contacts or component that causes a Circuit to Operate Poorly or not at all.
- <u>Short to Voltage</u> Having Voltage Present on a Wire that Should have No Voltage.
- <u>Short to Ground</u> Having a Connection to Ground where there should not be one.